DEMO Version [ventilationVest]

procool
PERSONAL CLIMATE SYSTEMS

Quick User Guide

DEMO Version [ventilationVest]

procool
PERSONAL CLIMATE SYSTEMS

Step 1

Slip into the vest and zip it up. Make sure the zipper is fully closed.

DEMO Version [ventilationVest]

procool
PERSONAL CLIMATE SYSTEMS

Step 2
Optionally zip up side zippers for closer fit.

Step 3

Tighten bottom cords and fix them at the required position by using the clips.

A pleasant wearing comfort should always be ensured!

Step 4

- **Insert air cartridges deep into the side pockets. (They must touch the bottom of the pocket)**
- **Cartridge orientation inside pockets: The power-on button points to the front, the round grill points to the back, the square grill points to the bottom.**
- **Make sure the zippers are fully closed.**

Step 5

Depending on how much cooling is required, switch on either one or both air cartridges, by pressing the square marking on the outside of the pocket.

DEMO Version [ventilationVest]

procool PERSONAL CLIMATE SYSTEMS

Quick User Guide

Innovative Cooling ©

by procool

ENTRAK GmbH & Co. KG, Richtweg 33, 90530 Wendelstein, GERMANY
www.procool.de